

Technique was achieved by brushing on two (2) layers of base glaze (SW-189 Cenote). Then apply two (2) layers of top glaze, letting glazes dry between coats.





SW-111 Wrought Iron *over* SW-189 Cenote





SW-143 Abalone **over** SW-189 Cenote









SW-148 Lime Shower **over** SW-189 Cenote





SW-153 Indigo Rain *over* SW-189 Cenote



SW-175 Rusted Iron **over** SW-189

Cenote





SW-181 Night Moth **over** SW-189 Cenote





SW-183 Oxblood **over** SW-189 Cenote





SW-189

Cenote





SW-203 Root Beer **over** SW-189 Cenote





SW-251 Pink Opal **over** SW-189 Cenote






SW-503 Orange Gloss **over** SW-189 Cenote















Technique was achieved by brushing on two (2) layers of base glaze (SW-189 Cenote). Then apply two (2) layers of top glaze, letting glazes dry between coats.





Wrought Iron over SW-189 Cenote





SW-143 Abalone over SW-189 Cenote





Cenote





SW-148 Lime Shower over SW-189 Cenote





Indigo Rain over SW-189 Cenote



SW-175 Rusted Iron over

SW-189

Cenote





SW-181 Night Moth over SW-189 Cenote





Oxblood over SW-189 Cenote





SW-189

Cenote





SW-203 Root Beer over SW-189 Cenote





Pink Opal over SW-189 Cenote





over SW-189 Cenote













